

# NX series

HANYOUNG NUX

## INSTRUCTION MANUAL

Thank you for purchasing Hanyoung Nux products. Please read the instruction manual carefully before using this product, and use the product correctly. Also, please keep this instruction manual where you can view it any time.

HANYOUNG NUX CO., LTD

28, Gilpa-ro 71beon-gil,  
Michuhol-gu, Incheon, Korea  
TEL : +82-32-876-4697  
http://www.hynux.com

MA0613KE200304

## Safety information

Please read the safety information carefully before the use, and use the product correctly. The alerts declared in the manual are classified into **Danger**, **Warning** and **Caution** according to their importance.

|                |  |
|----------------|--|
| <b>DANGER</b>  | Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury          |
| <b>WARNING</b> | Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury         |
| <b>CAUTION</b> | Indicates a potentially hazardous situation which, if not avoided, may result in minor injury or properties damage |

**DANGER**

- The input/output terminals are subject to electric shock risk. Never let the input/output terminals come in contact with your body or conductive substances.
- WARNING**
  - If there is a possibility of a serious accident due to malfunction or abnormality of this product, install an appropriate protection circuit on the outside.
  - Since this product is not equipped with a power switch and fuse, install them separately on the outside (fuse rating: 250V a.c. 0.5A.c.)
  - When changing the input sensor (default: K Type), first set the input group (G.In), then set the output group (G.Out), then set the other groups. If you change the data of the input group or the output group after setting other groups, the data of other groups that have already been set will be initialized.
  - Please supply the rated power voltage, in order to prevent product breakdowns or malfunctions.
  - To prevent electric shocks and malfunctions, do not supply power until the wiring is completed.

- The contents of this manual may be changed without prior notification. Make sure that the product specifications are the same as you ordered.
- When replacing the sensor, be sure to turn off the power.
- Use an extra relay for the control operation.
- Make sure that there are no damages or product abnormalities occurred during shipment.
- Use the product with the temperature range from 0 to 50 °C (max. 40 °C for close installation)/humidity range from 35 to 85% RH (without condensation).
- Use the product in places where corrosive gases (especially harmful gases, ammonia, etc.) and flammable gases are not generated.
- Use the product in places where vibrations and impacts are not applied directly to product body.
- Use the product in places without liquids, oils, chemicals, steam, dust, salt, iron, etc. (pollution degree 1 or 2).
- Do not wipe the product with organic solvents such as alcohol, benzene, etc. (wipe it with neutral detergents).
- Avoid places where large inductive interference, static electricity, magnetic noise are generated.
- Avoid places with heat accumulation caused by direct sunlight, radiant heat, etc.
- Use the product in places with elevation below 2000 m.
- When fixing the product to a panel, attach the two brackets on the fixing holes and tighten them with a screwdriver.
- The fixing torque is about 14.7 N · cm (1.5kg · cm).
- When water enters, short circuit or fire may occur, so please inspect the product carefully.
- For thermocouple input, use the predetermined compensating cable (temperature error is less than using ordinary cable).
- For RTD input, use cable with small lead wire resistance and without resistance difference among 3 wires (temperature errors occur if the resistance value among 3 wires is different).
- Use the input signal line away from power line and load line to avoid the influence of inductive noise.
- Input signal line and output signal line should be separated from each other. If separation is not possible, use shield wires for input signal line.
- Use a non-grounded sensor for thermocouple (using a grounded sensor may cause malfunctions to the device due to short circuits). When there is a lot of noise from the power, we recommend to use insulation transformer and noise filter. Please install the noise filter to a grounded panel or structure, etc. and make the wiring of noise filter output and product power supply terminal as short as possible.
- Tightly twisting the power cables is effective against noise.
- If the alarm function is not set correctly, it will not be output in case of abnormal operation, so please check it before operation.

## Suffix code

## ■ NX1 suffix code

| Model                | Code | Content   | Default       |
|----------------------|------|---|---------------|
| NX1-                 | -    | Multi Input/Output Temperature Controller, 48(W) X 24(H) mm |               |
| Control type         | 0    | Normal type   |               |
|                      | 1    | Heating/cooling control (simultaneous control)              |               |
| Normal type          | 0    | RET   | OUT1(RLY)     |
|                      | 1    | OUT1(SSR/SCR)   | OUT1(RLY)     |
|                      | 2    | RS485/RET   | OUT1(RLY)     |
|                      | 3    | RS485   | OUT1(SSR/SCR) |
| Heating/cooling type | 4    | ALM   | OUT1(SSR/SCR) |
|                      | 5    | RS485/ALM   | OUT1(SSR/SCR) |
|                      | 6    | RS485   | OUT2(SSR/SCR) |
|                      | 7    | RS485   | OUT1(SSR/SCR) |
|                      | 8    | RS485   | OUT2(SSR/SCR) |
|                      | 9    | RS485   | OUT1(RLY)     |
|                      | 10   | RS485   | OUT2(RLY)     |
|                      | 11   | RS485   | OUT1(SSR/SCR) |
|                      | 12   | RS485   | OUT2(SSR/SCR) |

※ OUT1: Heating output, OUT2: Cooling output

## ■ NX2, 3, 7, 9 suffix code

| NX2, 3, 7, 9 suffix code |      |   |         |
|--------------------------|------|---|---------|
| Content                  |      |   |         |
| Normal type              |      |   |         |
| Model                    | Code | Content   | Default |
| NX                       | -    | Multi Input/Output Temperature Controller, 48(W) X 96(H) mm |         |
| Size                     | 2    | 48(W) X 96(H) mm  |         |
|                          | 3    | 96(W) X 48(H) mm  |         |
|                          | 7    | 72(W) X 72(H) mm  |         |
|                          | 9    | 96(W) X 96(H) mm  |         |
| Control method           | 0    | Normal type (heating control)                               | 1       |
|                          | 1    | Heating/cooling (simultaneous) control                      | 4       |
| NX9 option               | 0    | None  |         |
|                          | 1    | RS485, HBA  |         |
| NX7 option               | 0    | None  |         |
|                          | 1    | RS485, HBA  |         |
|                          | 2    | SV2, SV3, HBA   |         |
|                          | 9    | RS485   |         |
| NX2, NX3 option          | 0    | SV2, SV3  |         |
|                          | 1    | HBA   |         |
|                          | 2    | RS485   |         |

※ RLY (Relay output), SSR (Voltage pulse output), SCR (Current output, 4-20mA d.c.), RET (Retransmission output)

**CAUTION**

## Control output wiring

When wiring or removing the control output, shut off the controller and external power supply, because there is a risk of electric shock.

Use shielded wires for voltage pulse output (SSR) and current output (SCR) wiring.

## ■ NX4 suffix code

| Model          | Code | Content  | Remarks  |
|----------------|------|--|--|
| NX4            | -    | Multi Input/Output Temperature Controller 48(W) X 48(H) mm |  |
| Control method | 0    | Normal type (heating control)                              | Default = 1  |
|                | 1    | Heating/cooling control (simultaneous control)             | Default = 4  |
|                | 2    | Heating/cooling control (NX4-20 only)                      |  |
|                | 0    | None   |  |
|                | 1    | HBA, AL2   | OUT1 (terminals ①-②-③) applied as AL1. (when selecting SSR / SCR control output) |
|                | 2    | SV2, SV3   |  |
|                | 3    | RET, RS485   |  |
|                | 4    | RS485  |  |
|                | 5    | AL1, AL2   | OUT1 (terminals ⑥-⑦) applied as SV2 (when selecting RELAY control output)        |
|                | 6    | AL1, AL2, SV2  |  |
|                | 7    | RS485, HBA   | OUT2 (terminals ⑧-⑨) applied as RLY.   |

※ OUT1(①-②-③) can be used for AL1 when AL1 is not selected.

※ OUT1: Heating control, OUT2: Cooling control

## ■ NX4 control output configuration (if the control output is SCR, the HBA can not be used)

| Normal type (heating) | Output | Heating side (OUT1) |                 | NX4-00        |                   | NX4-01                        |                           | NX4-02                                 |                   | NX4-03              |                                      | NX4-04            |                     | NX4-07            |                     | Default |
|-----------------------|--------|---------------------|-----------------|---------------|-------------------|-------------------------------|---------------------------|--|-------------------|---------------------|--------------------------------------|-------------------|---------------------|-------------------|---------------------|---------|
|                       |        | Relay (①-②-③)       | SSR / SCR (⑥-⑦) | Relay (⑩-⑪-⑫) | Transformer (⑬-⑭) | Alarms and transformers (⑮-⑯) | External input (DI) (⑯-⑰) | Communication and retransmission (⑯-⑰) | Transformer (⑯-⑰) | Communication (⑯-⑰) | Communication and transformers (⑯-⑰) | Transformer (⑯-⑰) | Communication (⑯-⑰) | Transformer (⑯-⑰) | Communication (⑯-⑰) |         |
|                       | 0      | RLY(ON/OFF)         | -               | -             | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 1      | AL1                 | SSR             | -             | -                 | AL2                           | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 2      | AL1                 | SCR             | -             | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 3      | RLY                 | -               | -             | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 4      | ALM                 | OUT1(SSR/SCR)   | ALM           | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 5      | RS485/ALM           | OUT1(SSR/SCR)   | ALM           | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 6      | RS485               | OUT1(SSR/SCR)   | ALM           | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 7      | RS485               | OUT2(SSR/SCR)   | ALM           | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 8      | RS485               | OUT1(SSR/SCR)   | ALM           | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 9      | RS485               | OUT2(SSR/SCR)   | ALM           | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 10     | RS485               | OUT1(SSR/SCR)   | ALM           | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 11     | RS485               | OUT2(SSR/SCR)   | ALM           | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |
|                       | 12     | RS485               | OUT1(RLY)       | -             | -                 | -                             | -                         | -                                      | -                 | -                   | -                                    | -                 | -                   | -                 | -                   | 1       |

※ NX4-01: HBA output is designated as 1-2-3 or 13-14 when selecting 21 for alarm type.

## ■ NX4-05

| Normal type (heating) | Output | Heating side (OUT1) |  | NX4-05 |  | NX4-06 |  |
|-----------------------|--------|---------------------|--|--------|--|--------|--|
|-----------------------|--------|---------------------|--|--------|--|--------|--|

